


PART DESCRIPTION

1. Screw holes
2. IR Output 3.5 mm jack socket
3. IR Output rising-cage Connectors
4. IR Status LEDs
5. Address/mode selector switch
6. Status LEDs
7. RS-485 jack
8. RS-232 & RS-485 jack
9. Rail mounting clips



CLIMAX[®]

Live in Harmony

INSTALLATION GUIDE version 1.0.1



IR Extender (CL-DR-IR8)

| Product Specification | Input Voltage | 8V-24V DC | |
|-----------------------|----------------------|----------------------------------------------------------------------------------|--|
| | Input Current | 100mA (for 24V DC) | |
| I/O Connections | C-Bus | 2 X RJ45 | |
| | RS-232 (Direct Mode) | 1 X RJ45 | |
| | Output | 8 X IR channel (4 X rising-cage 5mm screw terminals & 4 X 3.5 mm jack socket) | |
| | Input | 1 X IR input | |

PART DESCRIPTION

Change Module Address

The module address can be set from 0 to 31 means of a dip switch called “address/mode selector switch”. Before changing module address and module mode the main power must be disconnected. The address must be defined in binary. For instance to set address “21”, the dip switch must be as below:



⚠ Never set the address “0” and “1” as “0” is not valid in C-Bus protocol and “1” is always dedicated for GatewayPro module.

⚠ Check all C-Bus module addresses to avoid repetitive address allocation.

Switching between Direct Mode and Network Mode

To set the module in direct mode slip button #7 to “up” position or slide it “down” to set the module in network mode.




MOUNTING

Rail Mounting


IR Extender is designed to be installed on a standard 35 mm wide DIN rail (EN 50022, Bs5584).

Hook the module from the top, pull down the rail mounting clips, push the module to the rail and release the rail mounting clips.



Screw Mounting


Screw the module to any surface through 4 corner screw holes.



WIRING 1

⚠ **Before wiring the device, always unplug the main power**

Follow this wiring for direct or network use of modules.




⚠ **Use the terminator socket for the last module in C-Bus network.**

⚠ **Never connect other modules to "IR Extender" wrongly via "RS-232 jack". it may cause damage to the connected modules.**

5

WIRING 3

Follow this diagram to connect external power supply and more than one infrared transmitter to the rising-cage IR outputs.




⚠ **The maximum voltage for power supply is 24V. (400mA per channel)**

7

WIRING 2

Follow the diagram below to connect one infrared transmitter to the rising cage IR outputs.



6

SETUP & PROGRAMMING

Module's LEDs

- **Power:** When the module is connected to main power, "Power LED" will flash smoothly.
 - **Status:** When the module is connected to C-Bus network and receives valid data packets, "Status LED" flashes quickly. "Status LED" is "off" when the module doesn't receive any data. In direct mode, "Status LED" will flash once when the module receives a valid data packet from Home Controller.
- When the module is receiving invalid data packet, "Status LED" will remain "on" for 5 seconds.
- 👉 In some cases, when a new module is added to C-Bus network, "Status LED" might remain "on" for 5 seconds. This situation must not be considered as an error.
- **IR:** This LED flashes when the module is transmitting IR signal.
 - **Rec:** This LED flashes when the module is receiving signal to capture IR codes.
 - **Cap:** This LED flashes when the module captures IR codes.

8